

How to Install Edgers

Call 811, Common Ground Alliance, a minimum of 2 to 3 days before starting your project to have utilities marked.

- STEP 1. Stake Out/Remove Sod** – Lay out the project by using stakes with a string line or garden hose. Dig a trench 6 in wide and 4 in deep.
- STEP 2. Compact** – Firmly compact the soil in the bottom of the trench with a tamper. Place 1 in of paver base in the bottom of the trench and firmly compact.
- STEP 3. Lay Edgers** – Position edger units end to end in the trench. Using a rubber mallet, tamp the edgers firmly into place. Use a carpenter's level to ensure your edger units are uniformly level. Continue to place the units until the desired length of the project is finished.
- STEP 4.** If necessary, edger units may be cut by using a circular saw with a masonry blade or split with a hammer and chisel. Read and understand the operating manual before using a saw. Finish your project by firmly packing along sides of edger units and replace sod or mulch.

